

STYLEX


Model: Trim with Steel top

Disassembly and Recycling Document

Disassembly Time: 5min / No Special Training Required


Tools Required

- safety glasses
- 1/8" allen wrench
- Small Screw Driver
- 7/16" wrench



Wood Top

1. Flip the table upside down.
2. Use an 1/8" allen key to remove the socket button head cap screws holding the frame to the top (figure A1).



Metal Top

1. Flip the table upside down (figure B1).
2. Use a 7/16" wrench to remove nut from stud (figure B1).



Caesarstone Top

1. Flip the table upside down.
2. Use an 1/8" allen key to remove the flanged button head screw (No picture).

- Top
- Material: Steel, wood, glass, solid surface, caesarstone, laminate



- Frame
- Material: Steel



- Flanged button head screw 10-24 X.5"(Caesarstone)
- Material: Steel



- Socket cap screw 10-24 X.5"(Wood Top)
- Material: Steel



- Nut (Metal tops)
- Material: Steel

